

TOYOTA RAV4 (Front) SM5639



Our Precision, Your Advantage

When you replace the strut mount, you must check the shape of the piston rod. KYB shock absorbers 339031/32 have a flat surface and the strut mount must reflect this. These flat surfaces lock the piston rod in the installation position, allowing you to tighten or remove the nut. So, if you use the wrong strut mount, you are not able to assemble the parts correctly.

February 2016

KYB shock absorbers 339031/32



OE:

48609-0R010 & KYB SM5658
48609-42020
48619-0R010
48619-42010



OE:

48609-12500 & KYB SM5639
48609-12570
48609-42030
48609-42060

